



High Rise Door Fitting Instructions

Calypso Fitted Bathroom Furniture

Our high rise carcasses are used for two product configurations. For the 'full door' product, you are required to drill the third set of hinge holes on the top door.

Fitting the door:

- Take the relevant door for the top of the carcass and install all 3 hinges.
- Fit the top two hinges to the carcass using the pre-drilled holes.
- With the door open, use the bottom hinge holes to mark out drilling points.
- Fold back the hinge and drill your pilot holes
- Replace the hinge into the 'open' position, and screw the hinge in place

