



X-CALIBUR MATCH CO



- 1 - HANDLE
- 1a - BACKSTRAP 01
- 1b - BACKSTRAP 03
- 1c - BACKSTRAP 04
- 1d - BACKSTRAP 07
- 2 - FRAME INSERT
- 3 - SLIDE
- 4 - BARREL
- 5,1 - TAKEDOWN PLATE PIN.
- 5,2 - TAKEDOWN PLATE.
- 6 - TRIGGER
- 7 - HAMMER
- 8 - SLIDE STOP LEVER
- 9 - SEAR
- 10 - EJECTOR SIDE PLATE
- 11 - LOCKING PIN
- 12 - GUIDE ROD
- 14 - FIRING PIN
- 15 - REAR SIGHT ADJUSTABLE
- 16 - FRONT SIGHT FIBER OPTIC
- 17 - EXTRACTOR
- 18 - MAGAZINE RELEASE BUTTON
- 20 - MAGAZINE CATCH
- 21 - TRIGGER BAR
- 22 - SAFETY LEVER SPORT
- 23 - SAFETY BAR
- 24 - ARREST CLENCH. (INSERT BUSHING).
- 25 - TRIGGER BAR PIN
- 26 - SEAR SPRING
- 27 - TRIGGER BAR PIN
- 28 - SLIDE STOP SPRING
- 29 - EXTRACTOR BUSHING SPRING
- 30 - TRIGGER SPRING.
- 31 - MAGAZINE CATCH SPRING
- 32 - TAKEDOWN PLATE PIN SPRING
- 33 - HAMMER SPRING
- 35 - SIDE PLATE
- 36 - RECOIL SPRING
- 37 - MAGAZINE CATCH PIN
- 38 - SIDE PLATE PIN
- 39 - TRIGGER PIN
- 40 - EXTRACTOR BUSHING
- 41 - FRONT SIGHT PIN
- 42 - AUTO SAFETY LEVER PIN
- 43 - SEAR PIN
- 44 - HAMMER SPRING SUPPORT PIN
- 46 - SLIDE CATCH PIN
- 46a - SLIDE CATCH PIN
- 47 - FIRING PIN RETENTION PIN
- 49 - EXTRACTOR SPRING
- 51 - DISTANCE COLUMN
- 52 - HAMMER SPRING BACK STOP
- 160 - REAR SIGHT PIN
- 164 - OPTIC MOUNTING PLATE
- 165 - OPTIC MOUNTING SCREWS
- 166 - REAR SIGHT MOUNTING PLATE
- 167 - REAR SIGHT MOUNTING PLATE SCREWS
- 1 - MAGAZINE
- 1a, 1b, 1c, 1d - MAGAZINE INSERTS
- 2 - RECEIVER
- 3 - BARREL
- 4 - STOCK
- 5,1, 5,2 - TAKEDOWN PLATE
- 6 - TRIGGER
- 7 - HAMMER
- 8 - SLIDE STOP LEVER
- 9 - SEAR
- 10 - EJECTOR SIDE PLATE
- 11 - LOCKING PIN
- 12 - GUIDE ROD
- 14 - FIRING PIN
- 15 - REAR SIGHT ADJUSTABLE
- 16 - FRONT SIGHT FIBER OPTIC
- 17 - EXTRACTOR
- 18 - MAGAZINE RELEASE BUTTON
- 20 - MAGAZINE CATCH
- 21 - TRIGGER BAR
- 22 - SAFETY LEVER SPORT
- 23 - SAFETY BAR
- 24 - ARREST CLENCH. (INSERT BUSHING).
- 25 - TRIGGER BAR PIN
- 26 - SEAR SPRING
- 27 - TRIGGER BAR PIN
- 28 - SLIDE STOP SPRING
- 29 - EXTRACTOR BUSHING SPRING
- 30 - TRIGGER SPRING.
- 31 - MAGAZINE CATCH SPRING
- 32 - TAKEDOWN PLATE PIN SPRING
- 33 - HAMMER SPRING
- 35 - SIDE PLATE
- 36 - RECOIL SPRING
- 37 - MAGAZINE CATCH PIN
- 38 - SIDE PLATE PIN
- 39 - TRIGGER PIN
- 40 - EXTRACTOR BUSHING
- 41 - FRONT SIGHT PIN
- 42 - AUTO SAFETY LEVER PIN
- 43 - SEAR PIN
- 44 - HAMMER SPRING SUPPORT PIN
- 46 - SLIDE CATCH PIN
- 46a - SLIDE CATCH PIN
- 47 - FIRING PIN RETENTION PIN
- 49 - EXTRACTOR SPRING
- 51 - DISTANCE COLUMN
- 52 - HAMMER SPRING BACK STOP
- 160 - REAR SIGHT PIN
- 164 - OPTIC MOUNTING PLATE
- 165 - OPTIC MOUNTING SCREWS
- 166 - REAR SIGHT MOUNTING PLATE
- 167 - REAR SIGHT MOUNTING PLATE SCREWS



X-CALIBUR MATCH CO



- 1 - HANDLE
- 1a - BACKSTRAP 01
- 1b - BACKSTRAP 03
- 1c - BACKSTRAP 04
- 1d - BACKSTRAP 07
- 2 - FRAME INSERT
- 3 - SLIDE
- 4 - BARREL
- 5,1 - TAKEDOWN PLATE PIN.
- 5,2 - TAKEDOWN PLATE.
- 6 - TRIGGER
- 7 - HAMMER
- 8 - SLIDE STOP LEVER
- 9 - SEAR
- 10 - EJECTOR SIDE PLATE
- 11 - LOCKING PIN
- 12 - GUIDE ROD
- 14 - FIRING PIN
- 15 - REAR SIGHT ADJUSTABLE
- 16 - FRONT SIGHT FIBER OPTIC
- 17 - EXTRACTOR
- 18 - MAGAZINE RELEASE BUTTON
- 20 - MAGAZINE CATCH
- 21 - TRIGGER BAR
- 22 - SAFETY LEVER SPORT
- 23 - SAFETY BAR
- 24 - ARREST CLENC.
- 25 - (INSERT BUSHING).
- 25 - TRIGGER BAR PIN
- 26 - SEAR SPRING
- 27 - TRIGGER BAR PIN
- 28 - SLIDE STOP SPRING
- 29 - EXTRACTOR BUSHING SPRING
- 30 - TRIGGER SPRING.
- 31 - MAGAZINE CATCH SPRING
- 32 - TAKEDOWN PLATE PIN SPRING
- 33 - HAMMER SPRING
- 35 - SIDE PLATE
- 36 - RECOIL SPRING
- 37 - MAGAZINE CATCH PIN
- 38 - SIDE PLATE PIN
- 39 - TRIGGER PIN
- 40 - EXTRACTOR BUSHING
- 41 - FRONT SIGHT PIN
- 42 - AUTO SAFETY LEVER PIN
- 43 - SEAR PIN
- 44 - HAMMER SPRING SUPPORT PIN
- 46 - SLIDE CATCH PIN
- 46a - SLIDE CATCH PIN
- 46c - RETAINING SPRING.
- 47 - FIRING PIN RETENTION PIN
- 49 - EXTRACTOR SPRING
- 51 - DISTANCE COLUMN
- 52 - HAMMER SPRING BACK STOP
- 160 - REAR SIGHT PIN
- 164 - OPTIC MOUNTING PLATE
- 165 - OPTIC MOUNTING SCREWS
- 166 - REAR SIGHT MOUNTING PLATE
- 167 - REAR SIGHT MOUNTING PLATE SCREWS
- 7 - HAMMER
- 9 - SEAR
- 33 - SPRING
- 52 - SPRING
- 43 - SCREW
- 24 - SCREW
- 30 - SCREW
- 22R - SCREW
- 21 - TRIGGER BAR
- 22 - SAFETY LEVER SPORT
- 23 - SAFETY BAR
- 24 - ARREST CLENC.
- 25 - (INSERT BUSHING).
- 25 - TRIGGER BAR PIN
- 26 - SEAR SPRING
- 27 - TRIGGER BAR PIN
- 28 - SLIDE STOP SPRING
- 29 - EXTRACTOR BUSHING SPRING
- 30 - TRIGGER SPRING.
- 31 - MAGAZINE CATCH SPRING
- 32 - TAKEDOWN PLATE PIN SPRING
- 33 - HAMMER SPRING
- 35 - SIDE PLATE
- 36 - RECOIL SPRING
- 37 - MAGAZINE CATCH PIN
- 38 - SIDE PLATE PIN
- 39 - TRIGGER PIN
- 40 - EXTRACTOR BUSHING
- 41 - FRONT SIGHT PIN
- 42 - AUTO SAFETY LEVER PIN
- 43 - SEAR PIN
- 44 - HAMMER SPRING SUPPORT PIN
- 46 - SLIDE CATCH PIN
- 46a - SLIDE CATCH PIN
- 46c - RETAINING SPRING.
- 47 - FIRING PIN RETENTION PIN
- 49 - EXTRACTOR SPRING
- 51 - DISTANCE COLUMN
- 52 - HAMMER SPRING BACK STOP
- 160 - REAR SIGHT PIN
- 164 - OPTIC MOUNTING PLATE
- 165 - OPTIC MOUNTING SCREWS
- 166 - REAR SIGHT MOUNTING PLATE
- 167 - REAR SIGHT MOUNTING PLATE SCREWS
- 1 - HANDLE
- 2 - FRAME INSERT
- 3 - SLIDE
- 4 - BARREL
- 5,1 - TAKEDOWN PLATE PIN.
- 5,2 - TAKEDOWN PLATE.
- 6 - TRIGGER
- 7 - HAMMER
- 8 - SLIDE STOP LEVER
- 9 - SEAR
- 10 - EJECTOR SIDE PLATE
- 11 - LOCKING PIN
- 12 - GUIDE ROD
- 14 - FIRING PIN
- 15 - REAR SIGHT ADJUSTABLE
- 16 - FRONT SIGHT FIBER OPTIC
- 17 - EXTRACTOR
- 18 - MAGAZINE RELEASE BUTTON
- 20 - MAGAZINE CATCH
- 21 - TRIGGER BAR
- 22 - SAFETY LEVER SPORT
- 23 - SAFETY BAR
- 24 - ARREST CLENC.
- 25 - (INSERT BUSHING).
- 25 - TRIGGER BAR PIN
- 26 - SEAR SPRING
- 27 - TRIGGER BAR PIN
- 28 - SLIDE STOP SPRING
- 29 - EXTRACTOR BUSHING SPRING
- 30 - TRIGGER SPRING.
- 31 - MAGAZINE CATCH SPRING
- 32 - TAKEDOWN PLATE PIN SPRING
- 33 - HAMMER SPRING
- 35 - SIDE PLATE
- 36 - RECOIL SPRING
- 37 - MAGAZINE CATCH PIN
- 38 - SIDE PLATE PIN
- 39 - TRIGGER PIN
- 40 - EXTRACTOR BUSHING
- 41 - FRONT SIGHT PIN
- 42 - AUTO SAFETY LEVER PIN
- 43 - SEAR PIN
- 44 - HAMMER SPRING SUPPORT PIN
- 46 - SLIDE CATCH PIN
- 46a - SLIDE CATCH PIN
- 46c - RETAINING SPRING.
- 47 - FIRING PIN RETENTION PIN
- 49 - EXTRACTOR SPRING
- 51 - DISTANCE COLUMN
- 52 - HAMMER SPRING BACK STOP
- 160 - REAR SIGHT PIN
- 164 - OPTIC MOUNTING PLATE
- 165 - OPTIC MOUNTING SCREWS
- 166 - REAR SIGHT MOUNTING PLATE
- 167 - REAR SIGHT MOUNTING PLATE SCREWS