


Mini Oxo rect 4

recessed

5065, 5066


24W

Instrucciones de montaje/ Assembly instructions/ Instructions de montage/ Montageanleitung/ Istruzioni di montaggio




1.0

2.0



3.0 Disconnect the mains power before operating the power or CCT selection switch. 4.0



5.0

6.0