


Mini Oxo rect 6

recessed


5067, 5068

36W


Instrucciones de montaje/ Assembly instructions/ Instructions de montage/ Montageanleitung/ Istruzioni di montaggio





1.0




2.0



3.0 Disconnect the mains power before operating the power or CCT selection switch. 4.0



5.0



6.0