



Mini Oxo rect 2 recessed

recessed

5063, 5064



12W

Instrucciones de montaje/ Assembly instructions/ Instructions de montage/ Montageanleitung/ Istruzioni di montaggio





1.0

2.0



3.0 Disconnect the mains power before operating the power or CCT selection switch. 4.0



5.0

6.0