





SPS ADVANCE RT


QUICK START GUIDE

- SPS.750.ADV RT
- SPS.1000.ADV RT
- SPS.1500.ADV RT
- SPS.2000.ADV RT
- SPS.3000.ADV RT



1

SAFETY
support.salicru.com



USBID UPS


WINPOWER SOFTWARE:
support.salicru.com

USER'S GUIDE:
support.salicru.com


support.salicru.com
support@salicru.com
+34 93 848 24 00




3



4




5.0




OK

 220V / 230V / 240V
50 Hz / 60 Hz


5.1



5.2



5.3



6

