

## INSTALLATION AND SERVICE MANUAL



For Installation of Brisbane Pendant luminaires Model. BRB-95001, BRB-95011, BRB-95021, BRB-95031





## IMPORTANT NOTES: READ ALL INSTRUCTIONS THOROUGHLY AND CAREFULLY PRIOR TO INSTALL OF FITTING AND RETAIN FOR FUTURE REFERENCE

- 1 INSTALLATION MUST BE BY A REGISTERED ELECTRICAL CONTRACTOR.
- 2 ENSURE ELECTRICAL POWER SUPPLY IS SWITCHED OFF BEFORE AND DURING THE INSTALLATION.
- 3 REMOVE FIXING BRACKET (2) BY UNSCREW FIXING KNOB (3).
- 4 FIX FIXING BRACKET TO CEILING. FIXING SCREWS SUPPLIED BY OTHER.
- 5 CONNECT MAIN SUPPLY TO TERMINAL BLOCK. KEEP INCOMING CABLE AS SHORT AS POSSIBLE.
- 6 REPLACE CEILING ROSE (1) AND SECURE WITH FIXING KNOB (3).
- LIGMAN standard products are supplied with the control gear 220-240V 50/60Hz.

  The control gear for other voltages and frequencies is available upon request, please consult us for more details.
- LIGMAN luminaires are designed to conform IEC 60598 2-1 standard.

Technical amendments and modifications techniques reserved.

## Ligman Lighting

## **Europe Headquarters**

Ligman Europe s.r.o. VGP Park Usti nad Labem, P2 120, 40317 Prestanov Czech Republic Tel. +420 477 071 500 sales.cz@ligman.com Thailand Headquarters Ligman Lighting Co., Ltd. 17/2 Moo 4, Monthong, Bangnampreaw, 24150, Chachoengsao Tel: +66 33 026 082 info@ligman.com