



Cleaning and Maintenance Recommendations

For optimum maintenance, we recommend.

CLEAN ONLY WITH WATER AND DRY WITH A SOFT CLOTH.

Never use detergents containing sodium hypochlorite, hydrochloric acid, acetic acid and/or phosphoric acid, as they may cause significant damage to the faucet and its components. Different types of detergents should not be mixed, nor should abrasive products or steam cleaners be used, as high temperatures may damage the products.

If it is necessary to use a neutral detergent, it is recommended to use the appropriate dosage and not to spray the detergent directly onto the faucet. Instead, apply it to a non-abrasive cloth or sponge to prevent the product from entering the interior of the faucet and damaging any components.

Regular cleaning is recommended to prevent limescale build-up. To remove limescale deposits, it is recommended to dilute white vinegar with warm water at a 50% ratio and leave the part to be cleaned immersed in the solution for one hour.

