


ASSEMBLY INSTRUCTIONS

1. Ürünün, hareketli asma aparatını çevirerek halatı geçireceğiniz yön ile ilgili ayarı yapabilirsiniz. Aparatı ayarladıktan sabitlemek için M8 setskuru sıkın.
2. Asma aparatının bağlantısını sağlayan M10 anahar başlı civatayı gevşeterek, halatı geçirin. M10 somunu sıkarak montajı tamamlayın.
3. Ürünün elektrik bağlantısını gösterir.



4. Modül değişimini yapmak için; öncelikle ürünün elektrik bağlantısını Modül değişimini yapmak için; öncelikle ürünün elektrik bağlantısını kesmeniz gereklidir. Modül bağlantısını sağlayan 4 adet M4 civatayı söktükten sonra elektrik bağlantısını sağlayan soketleri birbirinden ayırın(Şekil 4.1), böylece modulu gövdeden ayırmış olursunuz. Bağlanacak yeni modülün elektrik soketlerini birleştirdikten sonra (Şekil 4.2), modülün gövdeye bağlantısını sağlayan civataları sıkın.

Driver değiştirmek için ürünün elektrik bağlantısını kestikten sonra haznenin kapağında bulunan 4 adet M5 alyan başlı civatayı sökün. Kontrol ünitesini dışarı doğru çekin.

Kontrol ünitesini hazneden çıkardıktan sonra, kartuş sacından M5 yıldız başlı civataları sökün

SELV (Safety Extra-Low Voltage)

Luminaire: IP66

Safety Standard: Class I

Impact strength: IK08

220-240 V AC 50-60 Hz

**WARNINGS AND REMARKS FOR
INSTALLATION AND MAINTENANCE****Safety Instructions** ⚠

- The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person. Always switch off the power prior to installation, maintenance or repair activities.
- The manufacturer is then discharged from liability when damage is caused by improper use or installation.
- If any luminaire is subsequently modified, the persons responsible for the modification shall be considered as manufacturer.
- To reduce the risk of death, personal injury or property damage from fire, electric shock, falling parts, cuts, abrasions and other hazards, please read all warnings and instructions included with the luminaire, on the luminaire's packaging and affixed to the luminaire itself..

Installation ⚠

- LEDs are high-quality electronic components! Please avoid contacting the light output opening of the LED directly during installation or relamping.
IMPORTANT ⚠
- To ensure secure connection, the luminaire housing must be positioned precisely in relation to the mounting plate.
Cleaning And Maintenance
- Clean luminaire regularly with solvent-free cleaners from dirt. Please do not do not clean the luminaire with using high-pressure liquids.

