

	INSTRUCTION MANUAL WOOD SAWS	Page	6
		Revision	00
		Date	15/05/2025
This manual is intended to guide the user in the safe and efficient use of this product			

1. IDENTIFICATION OF THE JOB AND TASKS

Manual tool with a toothed blade used to make cuts in wood, chipboard, or panels. Used in carpentry, assembly, DIY, and construction tasks for straight or angled cuts.

2. RISK ASSESSMENT

2.1. Risk Identification

- Severe cuts due to contact with the toothed blade.
- Impacts or sprains caused by tool slippage.
- Fatigue or muscle discomfort from prolonged use.
- Projection of splinters or particles during cutting.
- Loss of control due to improper grip or a worn blade.

2.2 Risk Assessment

Hazard	Consequence	Probability	Severity	Risk
Cuts	Minor or severe injuries	High	High	High
Slippage	Contusion or loss of control	Medium	Medium	Medium
Muscle fatigue	Pain or tendinitis	High	Medium	High
Splinter projection	Eye injury	Medium	High	High
Worn blade	Cutting failure	Medium	Medium	Medium

2.3. Preventive Measures

- Use cut-resistant gloves and safety goggles.
- Mark the cutting area beforehand for greater precision.
- Ensure an ergonomic posture and take regular breaks.
- Secure the wood piece with clamps before cutting.
- Check that the blade is sharp and the handle is firmly attached.
- Ensure a firm grip on the handle and control of the cut. Do not force the cut.
- Cut on a stable and clear surface.

2.4. Corrective Measures in Case of Accident

- Cuts: Clean, disinfect, and cover the wound. Seek medical attention if necessary.
- Eye injury: Rinse with clean water and go to emergency services.
- Fatigue or cramps: Stop the task and rest the affected area.

	INSTRUCTION MANUAL WOOD SAWS	Page	6
		Revision	00
		Date	15/05/2025
This manual is intended to guide the user in the safe and efficient use of this product			

2.5. Evaluation of the Effectiveness of the Measures

- Verify that appropriate personal protective equipment is used. Check the condition of the tool and reinforce training on safe cutting techniques.

3. INSTRUCTIONS FOR USE

3.1. Considerations Before Use

- Check that the blade is securely fixed, without excessive wear or corrosion.
- Secure the workpiece with clamps or stops.
- Use eye protection and cut-resistant gloves.

3.2. Considerations During Use

- Hold the saw firmly by the handle.
- Start the cut smoothly with controlled movements.
- Maintain a constant cutting angle and avoid forcing the blade.
- Remove chips and dust regularly to maintain visibility..

3.3. Warnings

- Do not use on materials for which it is not designed.
- Do not use if the tool is in poor condition: rusted, loose, or damaged.
- Do not cut on unstable or unbalanced surfaces.
- Do not perform cuts with one hand or without securing the workpiece.
- Do not leave the saw in walkways or unprotected areas.
- Do not point it at people or handle it unsafely.
- Do not allow use by minors or untrained persons.
- Do not use without eye protection or in low-visibility conditions.
- Ensure a firm grip on the handle and the workpiece.
- Do not apply excessive pressure to avoid damaging the blade or losing control during cutting.
- Use only under adequate lighting conditions.
- Do not use if experiencing fatigue, intoxication, or after taking medication or substances incompatible with the task.



4. MAINTENANCE AND STORAGE

	INSTRUCTION MANUAL WOOD SAWS	Page	6
		Revision	00
		Date	15/05/2025
This manual is intended to guide the user in the safe and efficient use of this product			

4.1. Cleaning

Clean the blade with a dry cloth after each use. Remove sawdust and apply lubricant if necessary.

4.2. Inspection

Check the condition of the blade and handle. Replace if there are cracks, rust, or loss of sharpness.

4.3. Storage

Store in a dry place, away from moisture. Use a protective cover if available.

4.4. Recycling and Environment

Dispose of at recycling centers in accordance with local regulations. Separate materials if possible.

5. CONTACT AND SUPPORT

If you have any questions or require further assistance, please do not hesitate to contact our customer service:

- **Email:** comercial@bellota.com
- **Phone:** 0034 943 73 90 00
- **Website:** www.bellota.com

We appreciate your trust in our products and are committed to ensuring your safety and satisfaction.