

|  |   |          |            |
|--|---|----------|------------|
|          | <b>INSTRUCTION MANUAL WOOD<br/>PUNCTURE SAW<br/>POINTE SAW FOR<br/>WOOD</b> | Page     | 6          |
|  |   | Revision | 00         |
|  |   | Date     | 15/05/2025 |
| This manual aims to <b>guide the user</b> in the safe and efficient use of this product. |   |          |            |

## 1. IDENTIFICATION OF THE JOB AND TASKS

A manual tool used for curved cuts, interior cuts, or cuts in hard-to-reach areas in wood. It is especially suitable for making holes or cuts starting from the center of the material without needing access from the edge.

## 2. RISK ASSESSMENT

### 2.1. Hazard Identification

- Cuts on hands from contact with the sharp tip or teeth of the saw.
- Blade slipping during the start of the cut.
- Muscle fatigue from prolonged use or incorrect technique.
- Projection of splinters or wood fragments.
- Handle breakage or blade deformation due to misuse.

### 2.2 Risk Assessment

| Hazard              | Possible Injury             | Probability | Severity | Risk Level |
|---------------------|-----------------------------|-------------|----------|------------|
| Cuts                | Minor or serious injuries   | High        | High     | High       |
| Slipping            | Loss of control             | Medium      | Medium   | Medium     |
| Muscle fatigue      | Pain, cramps                | High        | Medium   | High       |
| Projected splinters | Eye injury                  | Medium      | High     | High       |
| Tool breakage       | Accident or cutting failure | Medium      | Medium   | Medium     |

### 2.3. Preventive Measures

- Use cut-resistant gloves and safety goggles.
- Pre-mark the cutting area for greater precision.
- Maintain an ergonomic posture and take regular breaks.
- Check that the blade is sharp and the handle is secure.
- Ensure a firm grip on the handle and control of the cut. Do not force the cut.
- Cut on a stable and clear surface.

### 2.4. Corrective Measures in Case of an Accident

|  |   |          |            |
|--|---|----------|------------|
|          | <b>INSTRUCTION MANUAL WOOD<br/>PUNCTURE SAW<br/>POINTE SAW FOR<br/>WOOD</b> | Page     | 6          |
|  |   | Revision | 00         |
|  |   | Date     | 15/05/2025 |
| This manual aims to <b>guide the user</b> in the safe and efficient use of this product. |   |          |            |

- Cuts: Wash with soap and water, disinfect, and cover. Seek medical advice if the cut is deep
- Splinters in the eyes: Rinse with clean water and seek medical attention.
- Fatigue or cramps: Stop the task, stretch the affected area, and apply local cold or heat.

### **2.5. Evaluation of the Effectiveness of Measures**

- Monitor the condition of the saw and reinforce correct use through training in safe and ergonomic cutting techniques.

## **3. INSTRUCTIONS FOR USE**

### **3.1. Considerations for Preparing to Use the Tool**

- Check that the blade is sharp and free of deformation.
- Ensure the handle is secure and free of cracks.
- Wear gloves and safety goggles.

### **3.2. Considerations During Use**

- Position the tip of the saw at the marked starting point.
- Apply pressure and move gently forward to penetrate the wood.
- Continue the cut following the desired line with controlled movements.
- Avoid sudden changes in direction and pressure to prevent blade damage and ensure better control of the cut.

### **3.3. Warnings**

- Do not use on materials for which the tool is not designed.
- Do not use if the tool is in poor condition: rusted, loose, or damaged.
- Do not leave the saw in walkways or without protection.
- Do not point toward people or handle it in an unsafe manner.
- Do not allow use by minors or untrained persons.
- Do not use without eye protection or in low-visibility conditions.
- Ensure proper grip of both the handle and the workpiece.
- Do not apply excessive pressure to avoid blade damage or loss of control during cutting.
- Do not cut with one hand without properly securing the workpiece.
- Use only under adequate lighting conditions.

|  |   |          |            |
|--|---|----------|------------|
|          | <b>INSTRUCTION MANUAL WOOD<br/>PUNCTURE SAW<br/>POINTE SAW FOR<br/>WOOD</b> | Page     | 6          |
|  |   | Revision | 00         |
|  |   | Date     | 15/05/2025 |
| This manual aims to <b>guide the user</b> in the safe and efficient use of this product. |   |          |            |



## 4. MANTENIMIENTO Y ALMACENAMIENTO

### 4.1. Cleaning

Clean with a dry cloth after each use. Remove any sawdust or resin residues.

### 4.2. Inspection

Check the condition of the blade and handle. Replace if it is broken, dull, or shows rust.

### 4.3. Storage

Store in a dry place, protected from dust and moisture. Use a protective sheath if available.

### 4.4. Recycling and Environment

Take to a recycling collection point at the end of its service life. Separate wood and metal if possible.

## 5. CONTACTO Y SOPORTE

If you have any questions or need further assistance, please do not hesitate to contact our customer service:

- **Email:** [comercial@bellota.com](mailto:comercial@bellota.com)
- **Phone:** 0034 943 73 90 00
- **Website:** [www.bellota.com](http://www.bellota.com)

We appreciate your trust in our products and are committed to ensuring your safety and satisfaction.