



## CONNECTION



## **CONNECTION EXAMPLE**



## **DETECTION RANGE ADJUSTMENT**

It is possible to adjust the activation distance range between 5cm and 15cm by adjusting the potentiometer position:



Turn left (counterclockwise) to reduce the activation range.

Turn to the right (clockwise) to increase the activation range.