



CONNECTION



CONNECTION EXAMPLE



DETECTION RANGE ADJUSTMENT

It is possible to adjust the activation distance (D) range between 5cm and 15cm by adjusting the potentiometer position:



Turn left (counterclockwise) to increase the activation range.



Turn to the right (clockwise) to reduce the activation range.