



DRIVER OPTIONS*		P	I	
 NO DIM	0434-00-39	1W	350mA	1 to 12 Rhino
	0434-00-40	2W	700mA	1 to 12 Rhino
	0434-00-41	3W	1050mA	1 to 11 Rhino
 DALI / PUSH	0434-01-23	1W	350mA	1 to 20 Rhino
	0434-01-25	2W	700mA	1 to 20 Rhino
	0434-01-26	3W	1050mA	1 to 16 Rhino

220
240 V~

Driver must be placed on remote