



DRIVER OPTIONS*		P	I	
 NO DIM	0434-01-30	2,1W	250mA	1 to 3 Watty
	0486-04-35	3W	350mA	1 Watty
	0434-00-39*	3W	350mA	1 to 4 Watty
 DALI	0434-01-29*	2,1W	250mA	1 to 3 Watty
	0434-00-79*	3W	350mA	1 to 4 Watty

220
240 V~

*Driver must be placed on remote