


TRIMLESS TOOL D16 X D34mm A478-00-00




Suitable for:

Magnetic Connector | A435-01-00:

- Coco | A499-00-XX
- Fit 20 | A431-00-XX
- Fit 27 | A432-01-XX
- Flip | A492-00-XX
- iO Micro | A434-01-XX
- Plus Micro | A433-01-XX
- Six XS | A429-01-XX
- Top Micro | A430-01-XX

TRIMLESS TOOL D20 X D52mm A478-00-01




Suitable for:

Alaska Big | A455-XX-XX

Dune | A48X-XX-XX

Wire Trimless Accessory | A023-XX-XX

TRIMLESS TOOL D43 X D70mm A478-00-02




Suitable for:

Alaska Trimless Accessory | A401-10-XX

Shot Light Trimless Accessory | A269-00-00

Lens Light Trimless Accessory | A470-00-00

TRIMLESS TOOL D59 X D100mm A478-00-03




Suitable for:

Alaska Big Trimless Accessory | A426-10-00

Shot Light S Trimless Accessory | A463-00-00


TRIMLESS TOOL D79 X D86mm A478-00-04



Suitable for:

Shot Light S Flex | A477-00-00

TRIMLESS TOOL D79 X D120mm A478-00-05




Suitable for:

Shot Light M Trimless Accessory | A298-00-00

Buddy Trimless Accessory | A50X-10-90

TRIMLESS TOOL D105 X D145mm A478-00-06




Suitable for:

Buddy L | A56X-10-90

Strumento per apparecchi di illuminazione trimless

Trimless Tool è una fresa a tazza sviluppata per agevolare un'installazione facile e precisa delle versioni Trimless. Fornisce una sede di incastro esatta per allineare l'accessorio con il piano del soffitto e contemporaneamente fornisce anche il taglio necessario per incassare le controcasse dei nostri apparecchi di illuminazione nei pannelli di cartongesso.



INSTALLATION GUIDE

https://youtu.be/sa_xAgj4ji4