

Universal Holder Dracula (DH0001)

wall mounted holder for glove, face mask and tissue boxes with “teeth” which automatically adjust to hold any size of box firmly in place

Physical Specifications:

Material: Plastic
Colour: White

Order Codes and Size Information:

DH0001 | One Size

Packaging:

50 pieces per box

Conveniently keeps boxes of disposable gloves, face masks, tissues or wipes within reach when mounted near work area. Perfect for doctor’s offices, laboratories, industrial facilities or wherever efficiency counts. The spring-loaded clamp is adjustable to fit many box sizes

Features

- Easy to mount with two adhesive strips on the back, as well as two screw holes for stronger installation
- Internal adjustable size range: 102 - 138 mm
- Spring loaded mechanism holds box firmly in position
- “Teeth” to hold the box firmly in place
- Suited for Unigloves glove and face mask boxes
- Holds boxes up to 0.9kg
- Allows one-hand operation
- Suitable for use in hygienically sensitive areas such as hospitals, GP surgeries, food factories and care homes

Installation

Universal holder comes ready to install with 2 adhesive strips on the back, for mounting on smooth non-porous surfaces. Two screw holes have been provided, if stronger installation is required.

To insert box, push top of holder upwards with box as shown. The “teeth” will clamp down on box and hold it securely in place.

Sectors

The holder can be used in a wide range of workplaces and industries, including healthcare, industrial plants, janitorial and local authorities.



For more about our product range, please **click on the image**



UNIGLOVES UK
Registered in England No: 4010200
VAT registration 791817787

3 Ambley Green,
Gillingham Business Park,
Gillingham, ME8 0NJ, UK
+44 (0)800 049 6602
enquiries@unigloves.co.uk
uk.unigloves.com

UNIGLOVES GERMANY
Arzt- & Klinikbedarf
Handelsgesellschaft mbH

Camp-Spich-Straße 71
D-53842 Troisdorf,
Germany
+49 (0) 2241-9323-0
unigloves@unigloves.de
de.unigloves.com

