

NITREX

Nitrex 242D (242D*)

Foam nitrile / PU palm coating · hydrophobic treated 13 gauge seamless liner
 cut resistant level D · touch screen compatible · liquid resistant
 NitreGuard® Technology · OEKO-TEX® STANDARD 100

Physical Specifications:

Material: Nylon, HPPE, Glass
 Colour: Blue/ Black
 Coating: Foam Nitrile / PU

Order Codes | Sizing:

242D/06 | 6
 242D/07 | 7
 242D/08 | 8
 242D/09 | 9
 242D/10 | 10
 242D/11 | 11

Size 06 | XS Size 07 | S Size 08 | M
 Size 09 | L Size 10 | XL Size 11 | XXL

Packaging:

1 pair per polybag
 10 pairs per master polybag
 6 master polybags per case

Classification:



For more about the Nitrex range,
 please [click on the image](#)



Features

- Featuring Unigloves NitreGuard Technology
- 13 gauge seamless nylon liner with HPPE and encapsulated glass fibre
- Cut resistant level D
- Foam nitrile / PU flexible palm coating
- Hydrophobic treatment
- Touch screen compatible
- Elasticated knitted wrist
- Certified to OEKO-TEX® STANDARD 100

Benefits

- Unigloves NitreGuard Technology is awarded to gloves achieving a high-performance in the straight blade cut test
- Medium weight seamless, breathable, nylon liner with HPPE and encapsulated glass fibre is breathable and ideal for use in areas where cut protection is required
- EN ISO cut level D (≥15N & <22N) designed to protect against high level cut hazards
- The flexible foam nitrile coating is blended with PU and offers maximum abrasion and tear protection and an enhanced grip in dry, damp and oily conditions
- The hydrophobic treatment allows for water resistance on the back of hand whilst maintaining maximum breathability
- The product allows use of touch screens without having to remove the gloves and put hands at risk of injury
- Elasticated knitted wrist ensures a secure fit and keeps hands free of dust ingress
- Independently certified by OEKO-TEX®, tested for harmful substances

Sectors

- Construction
- Engineering
- Glass handling
- Local authority
- Recycling
- Manufacturing
- Railway maintenance
- Transportation
- Utilities
- Brewery
- Fisheries



UNIGLOVES UK
 Registered in England No: 4010200
 VAT registration 791817787

3 Ambley Green, Gillingham Business Park,
 Gillingham, ME8 0NJ, UK
 +44 (0)800 049 6602
 enquiries@unigloves.co.uk
 uk.unigloves.com

UNIGLOVES GERMANY
 Arzt- & Klinikbedarf
 Handelsgesellschaft mbH

Camp-Spich-Straße 71
 D-53842 Troisdorf
 +49 (0) 2241-9323-0
 unigloves@unigloves.de
 unigloves.de



Neither this document nor any other statement made herein by or on behalf of Unigloves should be interpreted as a guarantee of marketability or that any Unigloves product is fit for a particular purpose. Unigloves accepts no responsibility for the adequacy or suitability of a user's selection of gloves for their intended application.

Issue No. 2

Prepared at Gillingham
 on 12/02/25