



APPROPRIATE AREAS OF USE

- Wall use only
- Interiors Backsplashes
- Fireplace Surrounds
- No Wet Areas

SURFACE PREPARATION

Substrate Preparation

Appropriate substrates: concrete, masonry, existing well bonded ceramic tile, proper tiling underlayment over wood or steel framed construction.

General Substrate Requirements

All substrates must be flat, smooth and free of all surface contaminants that could act as a bond breaker. Overly absorbent as well as non-absorbent substrates require priming prior to installation. A surface flatness of ½" in 10' is required for all tile and stone installations per TCNA installation guidelines.

Crack Isolation

All existing substrates cracks as well as any area susceptible to future surface cracking requires the installation of a crack isolation membrane meeting ANSI 118.12.

Substrate Preparation Products

- ARDEX AM 100™ Rapid Set Pre-Tile Smoothing and Ramping Mortar
 ARDEX SKM™ Skimcoat Patch & Finish-
- ARDEX SKM[™] Skimcoat Patch & Finish ing Underlayment
- ARDEX 8+9[™] Rapid Waterproofing and Crack Isolation Compound

For complete information regarding substrate preparation requirements, material selection, required installation tools and application, visit www.ardexamericas. com and view the individual product technical data sheets or contact ARDEX technical service at (888) 512-7339

CUTTING & DRILLING

Use a diamond wet saw blade meant for cutting glass. We recommend the Husqvarna Superlok Glass+ blade.

To create holes, use a 3/8" drill with a water swivel attachment. Drill using diamond drill bit made for glass, at a slow speed.

For tiles, starting with the face of the glass, cut halfway through the material, then flip

and cut through the back. For mosaics, cut through the material in one pass and install quickly, as water may loosen the mosaic from the mesh. Cut only once. Use the tile saw blade or polishing pad to smooth the residual cutting marks from the tile or mosaic. Applying painters tape or masking tape to cutting liner can help reduce chipping. Cut slowly at a steady pace to prevent cracking or flaking the mirrored backing.

SETTING

Before installation, dry lay all material to inspect for quality and to determine the best blend of the material. All materials must be acclimated prior to installation, and air and surface temperature must be between 50° F and 80 °F during installation. Be sure to clean tiles to remove any dust, dirt or packing contaminants prior to installation.

Per ANSI A108.5, trowel apply mortar to the substrate. Flatten trowel marks to achieve a smooth, consistent setting bed. Back-butter glass tiles with mastic. Place tiles while material is wet and offers transfer. A minimum coverage of 80% for interior dry areas must be achieved. Once setting materials have adequately set (see product specifications for dry time) grouting can proceed. Honor all expansion and moving joints in accordance with TCNA EJ 171. In addition, all perimeter and change of plane areas must be filled with an appro-priate flexible sealant (ARDEX SXTM 100% Silicone Sealant for Tile and Stone Applications).

White mastic is recommended for all glass products. Ensure all grout joints are completely cleaned out prior to grouting.

Recommended Mortar and Adhesives

- •Locktite PL 530 Mirror, Marble, and Granite construction adhesive
- •Seal Bond CS-4300 Mirror Mastic
- •Geocel Mirror Fix (UK)
- Ever Build Mirror Mate (UK)

Recommended Grout

 \bullet ARDEX FG-CTM MICROTEC® Unsanded Grout

Caulking

• ARDEX SXTM 100% Silicone Sealant for Tile and Stone Applications

See complete setting material product technical information and installation instruction at ardexamericas.com.

SEALING

There is no need to seal glass tiles, however check with your grout manufacturer to see if your grout should be sealed.

Recommended Grout Sealer:

•FILAGROUT PROOF

For complete information regarding sealant products from FILA, visit filasolutions.com or call 844-FILA123

CARE & MAINTENANCE

For day-to-day cleaning, apply a pH neutral cleaner and scrub with a soft brush or soft pad. Remove the residue with a clean cloth or wet vac and rinse thoroughly.

Recommended Cleaners

- FILACLEANER
- FILACLEANER Spray

For complete information regarding care & maintenance products from FILA, visit filasolutions.com or call 844-FILA123

CAUTION

AKDO will not accept claims for any reason after the material has been cut, modified or installed

You have chosen to install your own Glass product. Neither AKDO Intertrade, Inc. ("AKDO") nor the manufacturer shall have any responsibility for damage to property or for personal injury resulting from or related to the installation process. You have determined the appropriate product and measurements for your needs. Except as otherwise set forth in writing, AKDO disclaims any and all representations and warranties regarding the suitability of the product for its intended use or the accuracy of measurements

Please read all instructions with care before beginning installation. These instructions are considered a guide, to help prevent problems caused by errors in installation.

(guidelines continued on next page)



The instructions should not be considered complete. Many details of installation are learned through experience and general construction knowledge, which we cannot provide. The installation guidelines are intended to be recommendations only, and they are not intended to serve as a step-by-step installation checklist.

Selection of an experienced installer is your sole responsibility. You should consult with a professional installer to determine the best installation procedure for your project. Installers should refer to the most current industry standards and specifications for installation. You assume all risks of loss or damage in connection with the installation and use of the Glass product.

TIPS FOR INSTALLING METALLIC GLASS MOSAICS

When using metallic glass in a backsplash design, include a 4" splash guard of wet area appropriate material in areas where water may pool, such as behind faucets.

For backsplash installations, the recommended distance between the tiles and electric heating element is 6" minimum and 8" minimum for gas heating element.